

ATTENTION:

BE SURE TO TIGHTEN
COMPRESSOR AND TURBINE
HOUSINGS ON TURBO AFTER
CLOCKING FOR YOUR
SPECIFIC VEHICLE

